


## SAFETY PRECAUTIONS AND WARNINGS

Here are a few safety precautions and warnings to help keep you safe when using the Cooking Stage. Failure to follow these warnings could lead to possible injury.

1. Be careful of the step up and down each time the product is used. Look at the step and be sure to use proper footing to avoid kicking or tripping. Failure to do so could lead to a slip, trip, or fall causing a serious injury.
2. Be careful stepping off of The Cooking Stage when carrying hot items. Falling with hot items might lead to injury.
3. Keep your weight centered on the Cooking Stage. Do not lean over the edge to reach something. Leaning over the edge of the Cooking Stage could lead to a trip or fall causing serious injury.
4. Avoid overloading the product by keeping the total weight on the product below 500 lbs. Overloading the product could cause product damage leading to serious injury. If product damage occurs, do not use the product and contact Customer Support.
5. Regularly inspect the product for damage of any kind. If damage is seen, do not use the product. Failure to stop using a damaged product can lead to serious injury. Contact Customer Support for a replacement product (pending product return).
6. Keep the plastic bag away from babies and children to avoid danger of suffocation possibly leading to death. Do not use in cribs, beds, carriages or playpens. This plastic bag is not a toy. Use caution and dispose of the bag properly.
7. Lifting or setting the product down could cause injury. Use proper lifting techniques by keeping your back straight up and lifting with your legs. If you have any back problems or injuries, please ask someone to help you place the product.

8. Make sure the non-slip feet are attached to the bottom of The Cooking Stage. If the non-slip feet are not installed, the product could slip on the floor when a person gets on or off. This could cause someone to lose balance and slip or fall causing injury.
9. Make sure the floor is clean and dry before every use. Test the Cooking Stage to see if it slides when pushed. Ensure that it is solid and sturdy before each use. If the product slides or is not sturdy – **DO NOT USE THE PRODUCT** until the situation is corrected. Call customer support to help fix any concerns in using the product. Failure to correct the problem can lead to serious injury.
10. Make sure the label (attached to the face of The Cooking Stage) is present whenever the product is used. This label provides important safety warnings. If the label is not on the product, call customer service for a replacement label.



# Instructions

1. Inspect your new Cooking Stage. Do not use the product if you find any damage. Call Customer Service and report the damage to obtain a replacement product (pending product return).
2. Place The Cooking Stage on a clean, dry, and level floor.
3. Keep your weight centered on The Cooking Stage. Don't lean over the edge of the Cooking Stage to reach something as this is not safe.
4. When carrying or placing The Cooking Stage, use proper carrying techniques to avoid back injury. Lift with your legs and avoid using your back.
5. Maximum allowable load is 500 lbs.
6. Clean with warm water and cloth. Dry completely before use. Do not use the product if it is wet or slippery.

the cooking stage

ENJOY COOKING AGAIN.

Product manufactured in China for Suintip

# MANUAL

## Instructions and Safety Precautions

the cooking stage

ELEVATE YOUR COOKING.

Thank you for purchasing The Cooking Stage.  
We hope you enjoy using this product as much as we do.



**Please read this entire manual before using this product.**

Failure to follow the instructions and safety precautions in this manual can result in serious injury.

Keep this manual in a safe location for future reference.

Visit [www.CookingStage.com](http://www.CookingStage.com) for additional information or replacement Instructions and Safety Precautions.



### CUSTOMER SERVICE:

(949) 534-1322

[support@CookingStage.com](mailto:support@CookingStage.com)



### COMMENTS AND FEEDBACK:

[feedback@cookingstage.com](mailto:feedback@cookingstage.com)

